



Assembly Instruction

Model: #1026

Description: QB & KB & CKB


Thank you for your support of our product. Be sure to check all packing material carefully for small parts that might have come loose during shipment.

Note: The lifts are engineered to properly accommodate a Saatva mattress. The lift will open and close smoothly with a mattress on it. If there is not a mattress on the lift, then the lift still operates but it is more difficult to close.

Part List					Part List			
No.	Description	Sketch	Size	Qty.	No.	Description	Sketch	Qty.
1	Bolt + (Lock & Flat Washer)		M6 x 25mm	10 Pcs	A	Headboard		1 Pc
2	Bolt + (Lock & Flat Washer)		M8 x 25mm	16 Pcs	B	Footboard		1 Pc
3	Bolt + (Lock & Flat Washer)		M8 x 50mm	4 Pcs	C	Side Rail (Left & Right) with Lifting Mechanism & Pistons		2 Pcs
4	Allen Key		M4	1 Pc	D	Top Panel (Front)		1 Pc
5	Allen Key		M5	1 Pc	E	Top Panel (Back)		1 Pc
6	Stud Bolt		M6 x 30mm	2 Pcs	F	Center Panel		1 Pc
7	Spanner			1 Pc	G	Bottom Panel		2 Pcs
					H	Metal Bracket		1 Pc
					I	Side Rail Bracket		2 Pcs


Step 1

- 1.1 - REMOVE WHITE WOVEN COVER THAT HELPS KEEP ITEMS CLEAN FROM BOTH CARTONS.
- 1.2 - TAKE OUT ALL PARTS.
- 1.3 - ASSEMBLY SIDE RAILS (C) TO HEADBOARD (A) WITH BOLT (3) AND ALLEN KEY (5).
- 1.4 - PLEASE DO NOT TIGHTEN THE BOLT.



Step 2

- 2.1 - PUT THE BOTTOM PANEL (G).



Assembly Instruction


Model: #1026

Description: QB & KB & CKB

Step 3

3.1 - ASSEMBLY CENTER PANEL (F) TO HEADBOARD (A) WITH BOLT (2) AND ALLEN KEY (5).


3.2 - PLEASE DO NOT TIGHTEN THE BOLT.



Step 4



4.1 - ASSEMBLY FOOTBOARD (B) TO SIDE RAILS (C), CENTER PANEL (F) WITH BOLT (2) AND ALLEN KEY (5).

4.2 - TIGHTEN THE BOLT (STEP 1), (STEP 3) AND (STEP 4).



Step 5

5.1 - ASSEMBLY SIDE RAIL BRACKET (I), FOOTBOARD (B) TO SIDE RAILS (C) USING BOLT (2) AND ALLEN KEY (5).



Assembly Instruction

Model: #1026

Description: QB & KB & CKB

Step 6


6.1 - LOOSEN THE HEX NUT ON THE LIFTING MECHANISM AND TAKE OUT THE PLASTIC WASHER.

6.2 - ASSEMBLY THE PISTONS AND THE PLASTIC WASHER(6.1).

6.3 - TIGHTEN THE HEX NUT WITH THE SPANNER(7).

6.4 - DON'T UNLOCK THE SAFETY LOCK UNTIL THE ASSEMBLY WAS DONE.


**(A SAFETY LOCK TO KEEP THE STORAGE BED OPEN. ESPECIALLY USEFUL WHEN YOUR MATTRESS IS HEAVY. ACCESS YOUR STORAGE EFFORTLESSLY.)*



Step 7

7.1 - ASSEMBLY THE STUD BOLT (6) TO TOP PANEL (FRONT) (D).

7.2 - ASSEMBLY THE METAL BRACKET (H) TO TOP PANEL (FRONT) (D) WITH BOLT (1) AND ALLEN KEY (4).




Step 8

8.1 - ASSEMBLY THE TOP PANEL (FRONT) (D) TO THE LIFTING MECHANISM WITH BOLT (1) AND ALLEN KEY (4).

(THE PURPOSE STUD BOLT IS LET THE TOP PANEL (FRONT) HANG ON THE LIFTING MECHANISM AND EASLIER FOR ASSEMBLY THE OTHER BOLT.)

8.2 - TIGHTEN THE BOLT AFTER ALL THE BOLT MEET THE HOLES.




Assembly Instruction

Model: #1026

Description: QB & KB & CKB

Step 9


9.1 - ASSEMBLY THE TOP PANEL (BACK) (E) TO LIFTING MECHANISM WITH BOLT (1) AND ALLEN KEY (4).



Step 10

10 - UNLOCK THE SAFETY LOCK AND PULL DOWN THE TOP PANEL (D + E) WITH MATTRESS.

PLEASE UNLOCK THE SAFETY LOCK AT LEAST 90 DEGREES . IF THE SAFETY LOCK STAY ON 45 DEGREES, THE PISTONS MAY CAUSE THE SAFETY LOCK DAMAGE WHEN PUSH DOWN THE TOP PANEL (D+E).



COMPLETED

